

은혜관 1층



AP



측정위치



-45dbm

매우 좋음



-55dbm

좋음




-65dbm

보통



-75dbm

약함



측정 위치	신호세기	Through Put Up/Down	
1	-34dbm	198M	228M

은혜관 2층



AP



측정위치



-45dbm

매우 좋음



-55dbm

좋음




-65dbm

보통



-75dbm

약함



측정 위치	신호세기	Through Put Up/Down	
		Up	Down
1	-45dbm	217M	319M
2	-44dbm	156M	291M
3	-61dbm	145M	323M
4	-50dbm	143M	205M
5	-44dbm	232M	325M

은혜관 3층



AP



측정위치



-45dbm

매우 좋음



-55dbm

좋음




-65dbm

보통



-75dbm

약함



측정 위치	신호세기	Through Put Up/Down	
		Up	Down
1	-56dbm	192M	212M
2	-50dbm	233M	188M
3	-58dbm	171M	243M
4	-59dbm	211M	239M
5	-60dbm	145M	125M
6	-57dbm	208M	251M
7	-65dbm	102M	109M
8	-43dbm	225M	323M
9	-50dbm	216M	285M
10	-44dbm	287M	340M

은혜관 4층



AP



측정위치



-45dbm

매우 좋음



-55dbm

좋음




-65dbm

보통



-75dbm

약함



측정 위치	신호세기	Through Put Up/Down	
		Up	Down
1	-42dbm	208M	251M
2	-50dbm	228M	273M
3	-60dbm	159M	138M
4	-50dbm	176M	233M
5	-60dbm	146M	227M
6	-50dbm	223M	329M
7	-50dbm	172M	246M
8	-49dbm	230M	299M
9	-41dbm	189M	219M
10	-50dbm	200M	297M
11	-46dbm	273M	326M
12	-39dbm	275M	321M

은혜관 5층



AP



측정위치



-45dbm

매우 좋음



-55dbm

좋음




-65dbm

보통



-75dbm

약함



측정 위치	신호세기	Through Put Up/Down	
		Up	Down
1	-45dbm	209M	227M
2	-44dbm	205M	334M
3	-60dbm	141M	206M
4	-45dbm	194M	239M
5	-43dbm	191M	229M
6	-39dbm	217M	319M